feet, for vessels owned or operated by the U.S. Government, the State of Massachusetts, or by local authorities.

- (c) Each opening of the draw, from the time vehicular traffic flow is stopped until the flow resumes, shall not exceed 15 minutes except for vessels whose draft exceeds 15 feet or in extraordinary circumstances.
- (d) From 6 p.m. on December 24 to midnight on December 25 and from 6 p.m. on December 31 to midnight on January 1, the draw shall open on signal if at least a two-hour notice is given by calling the number posted at the bridge.

[CGD 1-84-10R, 49 FR 36841, Sept. 20, 1984, as amended by CGD01-00-135, 65 FR 38207, June 20, 2000]

# § 117.586 Annisquam River and Blynman Canal.

The draw of the Blynman (SR127) Bridge shall open on signal, except that, from noon to 6 p.m. on Thanksgiving Day, 6 p.m. on December 24 to midnight on December 31 to midnight on Danuary 1, the draw shall open on signal if at least a two-hour advance notice is given by calling the number posted at the bridge.

[CGD01-04-096, 69 FR 67058, Nov. 16, 2004]

### §117.587 Apponagansett River.

- (a) The draw of the Padanaram Bridge mile 1.0 shall open on signal 1 May through 31 October from 5 a.m. to 9 p.m. daily as follows:
- (1) The bridge shall open on signal, twice an hour, on the hour and the half hour between 5 a.m. and 9 a.m. and between 8 p.m. and 9 p.m.
- (2) The bridge shall open on signal, once an hour, on the hour between 9 a.m. and 8 p.m.
- (b) At all other times the bridge shall open if at least four (4) hours advance notice is given.
- (c) The owners of this bridge shall provide and maintain mooring facilities for vessels to make fast while waiting for the bridge to open.
- (d) The owners of this bridge shall provide and keep in good legible condition, clearance gauges for each draw with figures not less than twelve (12) inches high designed, installed and

maintained according to the provisions of section 118.160 of this chapter.

[CGD01-95-008, 60 FR 29761, June 6, 1995]

#### §117.588 Bass River.

The Hall Whitaker Bridge, mile 0.6 at Beverly, shall operate as follows:

- (a) Public vessels of the United States must be passed as soon as possible.
- (b) The owners of this bridge shall provide and keep in good legible condition clearance gauges for each draw with figures not less than 12 inches high designed, installed and maintained according to the provisions of §118.160 of this chapter.
- (c) That the drawspan for the Hall Whitaker Drawbridge must open on signal if at least 24 hours notice is given.

[CGD1-91-015, 56 FR 41460, Aug. 21, 1991, as amended by USCG-2001-10881, 71 FR 70311, Dec. 4, 2006]

## §117.589 Cape Cod Canal.

The draw of the Conrail railroad bridge, mile 0.7 at Bourne, shall operate as follows:

- (a) The draw is normally in the fully open position except for the passage of trains or for maintenance. No signal is required if the draw is in the fully open position.
- (b) If the draw is not in the fully open position, the opening signal is one prolonged and one short blast.
- (c) Signals to be sounded from the bridge are—
- (1) Immediately preceding the opening of the draw, one prolonged blast;
- (2) Immediately preceding the closing of the draw, two prolonged blasts;
- (3) When a vessel has sounded the opening signal and the draw cannot be opened immediately, five short blasts in a rapid succession; and
- (4) When the draw is closed and visibility is reduced in foggy weather, five short blasts in rapid succession every two minutes.

## §117.591 Charles River and its tributaries.

(a) The following requirements apply to all bridges across the Charles River and it's tributaries: